



**534J Installer's
Checklist**

Installation Steps—Use this checklist AND the engine and accessories installation manuals.

1. You need to know:	12. Install and connect the venting system. Seal pipes joints.
• front and accessories to use	13. Install the electrical wiring to the fireplace if required.
• required cavity size and hearth finish	14. If the appliance needs gas conversion, convert the appliance now with the optional kit listed in the appliance manual.
• thickness and type of wall finish around appliance opening	15. Connect the gas line to the appliance and test for gas leaks.
• venting configuration - top, rear, co-linear	16. Install the fan (blower) if used.
• optional accessories if any (fan)	17. Install the liner panels in the firebox.
2. Carefully unpack the appliance and loose items packed with it and all accessories; recycle the packaging.	18. Install the fuel bed in the firebox.
3. Remove the window and set aside in a safe place to avoid damage.	19. Refit the window. Check spring-loaded window return.
4. Take out of the firebox any loose items packed inside for transportation.	20. Reinstall the Hot Glass Warning plate on the window if it has been removed.
5. Check that you have all the components in hand for the installation. This includes:	21. Put batteries in battery holder and handset.
• liner panels (in separate cartons)	22. Pair remote control receiver and handset.
• fuel bed (in separate cartons)	23. Check burner lighting and adjust the aeration settings if necessary.
• front, trim including barrier screen, fret	24. Install the remote control handset wall holder as required.
• gas conversion kit if required	25. Install the front, trim and barrier screen.
• venting components and accessories	26. INSTRUCT THE CONSUMER ON HOW TO OPERATE AND MAINTAIN THE FIREPLACE.
• electrical parts for optional accessories	<ul style="list-style-type: none"> • show where the controls AND BATTERIES are (gas valve, receiver, battery holder, accessories) and how to access them • show how to operate the remote control, accessories • show how to turn the fireplace off in case of emergency
6. Look up dimensions, clearances, hearth requirements and venting information in the installation manuals supplied with the appliance, trims and accessories to ensure that the cavity is of appropriate dimensions.	Leave <u>all</u> instruction manuals and documents, including this one, with the consumer.
7. Install stand-offs, heat shield and supports..	
8. Convert appliance venting outlet if needed - rear or co-linear.	
9. Install 817VAK or co-linear vent adapter.	
10. Install restrictors.	
11. Install the appliance in the cavity.	



534J Aide-mémoire de l'installateur

Étapes d'installation—Utilisez cette liste ET les guides d'installation du foyer et des accessoires

1. Obtenez l'information suivante :	12. Installez le système d'évacuation et scellez les joints des conduits.
• devanture et bordure à installer	13. Installez le câblage électrique si nécessaire.
• dimensions de cavité et finition de dalle	14. Si l'appareil requiert la conversion de gaz, convertissez-le maintenant avec la trousse de conversion appropriée.
• épaisseur et matériaux de finition autour de l'ouverture du foyer	15. Raccordez l'alimentation de gaz à l'appareil et vérifiez s'il y a des fuites de gaz.
• évacuation - dessus/arrière/colinéaire	16. Installez le ventilateur si utilisés.
• accessoires optionnels, si utilisés	17. Installez les panneaux intérieurs.
2. Déballez soigneusement l'appareil, les articles l'accompagnant et les accessoires; recyclez les emballages.	18. Installez le lit de combustion.
3. Enlevez la fenêtre de l'appareil et mettez-la de côté pour éviter de l'endommager.	19. Reinstallez la fenêtre et vérifiez son mécanisme à ressort.
4. Enlevez de l'intérieur de l'appareil tout article y ayant été placé pour le transport.	20. Installez le côté français de la plaquette de sécurité vitre chaude dans le cadre extérieur de la fenêtre.
5. Assurez-vous d'avoir en main tout le nécessaire à l'installation incluant :	21. Mettez des piles dans le porte-piles et dans la manette de télécommande.
• panneaux (emballés séparément)	22. Synchronisez le récepteur à la manette.
• lit de combustion (emballé séparément)	23. Vérifiez l'allumage et ajustez l'aération si nécessaire.
• devanture, bordure avec pare-étincelles	24. Installez le support mural de manette.
• trousse de conversion de gaz si utilisée	25. Installez la bordure avec pare-étincelles.
• accessoires d'évacuation	26. MONTREZ AU CONSOMMATEUR COMMENT UTILISER ET ENTRETENIR LE FOYER.
• accessoires électriques si utilisés	• montrez où sont les commandes ET LES PILES (soupape à gaz, récepteur, porte-piles, accessoires) et comment y accéder.
6. Consultez les guides d'installation du foyer, devanture et bordure pour connaître les dimensions, dégagements, exigences relatives à la dalle et au système d'évacuation afin de vous assurer que la cavité soit de dimensions requises.	• montrez comment fonctionne la télécommande et accessoires.
7. Installez les écarteurs, paroi de protection et supports.	• montrez comment éteindre le foyer en cas d'urgence.
8. Convertissez l'évent de l'appareil si nécessaire - évent arrière ou colinéaire.	Remettez au consommateur <u>tous</u> les guides d'installation et documents, incluant celui-ci.
9. Installez adaptateur 817VAK ou colinéaire.	
10. Installez les restricteurs d'air.	
11. Installez l'appareil dans la cavité.	