


1100J/1150J H5 Direct Vent ZC **Co-axial Venting**


How to Read the Venting Chart

The chart below applies to co-axial roof or wall termination.

- Maximum 12 inch horizontal pipe section allowed with 1. no vertical in vent system.
- The total length of the vent pipe cannot exceed 2. 40 feet.
- 3. The minimum vertical height with roof termination is 6 feet.
- 4. Any combination of rise and run can be used as long as they are within the allowable limits shown on the chart below.
- A maximum of 4 x 90 degrees elbows—or equivalent 5. (2 x 45 degrees = 90 degrees)—can be used. Excludes the 45 degrees take-off elbow shipped with the appliance.
- Venting Chart



- Each 90 degrees elbow installed on the horizontal 6. plane is equivalent to a 3 feet horizontal pipe; therefore. 3 feet must be subtracted from allowable horizontal run. (45 degrees elbow is equivalent to 18 inches horizontal pipe.)
- 7. All horizontal pipe runs must be graded 1/4 inch per foot upwards in the direction of the exhaust flow. The final pipe length, when terminating through the wall may be graded downwards slightly to prevent water migration.
- 8. A restrictor adjustment is required for most installations having a vertical rise-see next section. Note: The restrictors are shipped loose with the appliance.



Allowable Co-Axial Vent Configurations with restrictor positions

Miles Industries Ltd. • 190—2255 Dollarton Highway • North Vancouver, BC • V7H 3B1 Tel: 604.984.3496 or 1.800.468.2567 • Fax: 604.984.0246 or 1.800.268.0333 www.valorfireplaces.com